

**IMPORTANT INFORMATION**  
**When Installing AROFLY on the**  
**PRESTA AND SCHRADER CYCLE TIRE VALVES**

**(A) AROFLY installation on the cycle Schrader Valve (also known as American Valve)**

1. The Schrader valve does not require an ADAPTOR.
2. Please ensure to secure the AROFLY tightly on the Schrader valve before cycling.

**IMPORTANT TO NOTE:** The Schrader valve needle must be in line with the opening of the stem. If the Schrader valve pin is lower than the top of the stem, it will not make a good contact with the AROFLY and hence the Cadence/Power and other data reading will not display on the APP. Please refer to below pictures. (Please see below pictures for reference)



**( B) AROFLY + ADAPTOR on Presta Valve ( also known as French valve )**

1. Before installing the ADAPTOR on the Presta valve, loosen the Presta valve screw all the way to the top of the stem. (please see below Pic#1 & #2)
2. Then screw the ADAPTOR on the Presta valve. (please see below Pic#3)
3. Final step is to screw AROFLY on the ADAPTOR, ensure it is secured tight. (please see below Pic#5)

**IMPORTANT TO NOTE:** The Presta valve needle must be in line with the opening of the stem of the ADAPTOR. If the Presta valve pin is lower than the top of the stem of the ADAPTOR, it will not make a good contact with the AROFLY and hence the Cadence/Power and other data reading will not display on the APP. (please see below Pic#4)



**Pic#1**



**Pic #2**



**Pic#3**



**Pic#4**



**Pic#5**